



DisplayShelf for
SNES Cartridges

(IN DAD'S MOST ANGRY VOICE)

DO NOT CLEAN ANY ACRYLIC WITH RUBBING ALCOHOL. IT WILL CAUSE FRACTURES IN THE PLASTIC AND IT WILL CRACK.

PROTECTIVE FILM NOTICE

Before you assemble your stand, you will need to remove this super annoying protective film from each piece. We would have rather done this for you, and we did try – but no matter what we did, we could not keep our greasy fingerprints off of the plastic. **We did include* a small removal tool. You can use this to peel away the protective film.**

ASSEMBLY

Be careful when assembling the stand. Acrylic cracks pretty easily, and one rough push could be a devastating one, so take your time. See reverse side of this page.

1. With each piece properly facing up, take the coloured base first and place it down on a flat surface.
2. Take the second clear base and place it on top of the coloured base. See Figure 1 and 2.
3. Insert the two clear connector pieces in the slots on the bases. See Figure 3 and 4.
4. Slide your cartridge onto the connector pieces. See Figure 5.

That should do it! If it didn't go the way you hoped, please let me know! Contact me via the platform you purchased, or nick@gameshelf.games.

If you're unhappy for whatever reason, please give me a chance to correct your experience – contact me first! I will make it right.

* While supplies last. We occasionally have trouble sourcing the small film removal tool at a price that we can include it for free.

FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 4




FIGURE 5

